



TIME DRY CYCLES

- 1 Set to any Time Dry setting
- 2 Choose any fabric selector setting
- 3 Choose any signal setting
- 4 On or Off

SANITIZE CYCLE

- 1 Set to Time Dry Max Dry
- 2 Set to Regular
- 3 Choose any signal setting
- 4 On or Off

AUTOMATIC CYCLES

- 1 Set to any Automatic Perm Press /Knits, Automatic Regular/Delicate, or Automatic Wrinkle Out setting
- 2 Choose any fabric selector setting
- 3 Choose any signal setting
- 4 On or Off