

DRYER CYCLE CONFIGURATIONS
AUTO-SENSING CYCLES

- 1 Set to Auto-Sensing
- 2 Choose any fabric selector cycle
- 3 Choose any auto-dryness setting
- 4 Available with most cycle settings*

SANITIZE CYCLE

- 1 Set to Sanitize
- 2 Selection ignored
- 3 Ignored unless set to Dry & Extended Tumble
- 4 Available

NO HEAT CYCLE


- 1 Set to No Heat 60 Min
- 2 Selection ignored
- 3 Selection ignored unless set to Dry & Extended Tumble
- 4 Not available

TIME DRY CYCLES

- 1 Set to Time Dry 30 or 60 (minutes)
- 2 Choose any fabric selector cycle
- 3 Selection ignored unless set to Dry & Extended Tumble
- 4 Not available

STEAM REFRESH CYCLE

- 1 Set to Steam Refresh
- 2 Delicate, Perm Press or Regular settings give 30 minutes of medium heat. Heavy Duty setting gives 20 minutes at high heat.
- 3 Selection ignored unless set to Dry & Extended Tumble
- 4 Not available



* Not available with Delicate cycle or with Less Dry auto-dryness setting; not available with Regular cycle when Near Dry auto-dryness is set